SAMBA FILE SERVER

```
1) Samba is popular local network file hosting server service. Firstly install program:
     # sudo apt-get install samba cifs-utils
2a) edit configuration file – full access privileges for #userSamba:
    # sudo vim /etc/samba/smb.conf
[shareName]
  path = /pathToShareFolderIncludingContent
  force user = userSamba
  force group = root
  create mask = 0777
  directory mask = 0777
  hosts allow = WhiteListIPAddr
  read only = no
  public = no
  guest ok = no
  writable = yes
P.S. userSamba username must exist in system – create one: #sudo useradd userSamba.
  3a) add authorized user #userSamba to program Samba
# sudo smbpasswd -a userSamba
  2b) edit configuration file – full access privileges for everyone:
     # sudo vim /etc/samba/smb.conf
    [shareName]
       path = /pathToShareFolderIncludingContent
       force user = root
       force group = root
       create mask = 0777
       directory mask = 0777
       hosts allow = WhiteListIPAddr
       read only = no
       public = yes
       guest ok = ves
       writable = yes
  4) restart Samba
     # sudo service smbd restart
  5) check configuration
    # sudo testparm
  6) list actually connected clients to file servers:
    #sudo smbstatus
7) enable firewall samba ports
    #sudo ufw allow 139 445 && sudo ufw reload
LINUX client to file server:
1a) load configuration at startup ( note that password is clearly shown in system! ):
        sudo mkdir /mnt/mountedClientFolder
     #
         sudo vim /etc/fstab
//serverIPAddr/shareName
                                              /mnt/mountedClientFolder
                                                                                              cifs
username=userSamba,password=admin1,uid=userSamba 0 0
 2a) restart configuration
     # sudo mount -a
1b) load configuration at startup with bash script:
  create one at home directory:
       #touch sambaClientMount.sh
  edit script to add mount point device:
```

#!/bin/sh

sudo mount //serverIPAddr/shareName /mnt/mountedClientFolder username=userSamba,password=admin1,uid=\$(id -u),gid=\$(id -g)

-0

WINDOWS client to file server:

MyComputer PPM: add network localization Check non-standard network localization; Next Server Address: \\serverIPAddr\shareName